




INSTALLATION AND OPERATION INSTRUCTIONS FOR

E 50

E 70



SAFETY INFORMATION



WARNING

For yo r !"# \$ % & ' (" y !) o * + ' y (, % - ' " " (" r . , , / ! " . 0 ! " # \$ % y , , ! % r) % o . !) o . % " , , \$ 0 , , % - , ! * " . ' " % o + r \$ 1 \$. % + \$ r ! o . ' " , , 2 ry or + ro + \$ r % 0 " * " / \$.

Do not store or use gasoline or other flammable vapors and liquids in the vicinity of this appliance.

INSTALLER: LEAVE OWNER'S MANUAL WITH THE APPLIANCE.

CONSUMER: RETAIN OWNER'S MANUAL FOR FUTURE REFERENCE.



WARNING: This product can expose you to chemicals including Lead in the wiring, which is [are] known to the State of California to cause birth defects or other reproductive harm. For more information visit: www.p65warnings.ca.gov

Please read and carefully follow all instructions found in this manual. Please pay special attention to the safety instructions provided in this manual. The instructions included here will assure that you have many years of dependable and enjoyable service from your Amantii product.

Table of Contents

IMPORTANT INSTRUCTIONS.....	3
UNPACKING AND TESTING APPLIANCE	4
GROUNDING APPLIANCE.....	4
CHOOSING FIREPLACE LOCATION.....	4
VIRTUS 50.....	5
VIRTUS 70.....	6
MEDIA OPTIONS.....	7
OPERATION	8
MANUAL OPERATION	8
AUTO MODE	8
REMOTE CONTROL OPERATION	9
REPLACEMENT PARTS.....	10
EXPLODED VIEW	11
WIRING DIAGRAM	12
TROUBLE SHOOTING	13
SERVICE HISTORY	14
WARRANTY	15

15 PO' TANT INST' UCTIONS

PLEASE RETAIN THIS USER GUIDE FOR FUTURE REFERENCE

When using electrical appliances ! asic precauti" ns sh" ul# al\$ a% ! e & ll" \$e# t" re#uce the ris' " &&re electric sh" c' an# in(ur%&" pers" ns inclu#ing the & ll" \$ing)

- * + Rea# all instructi" ns ! e&re using this &replace
- , + The &replace is h" t \$hen in use- T" a. " i# ! urns # " n" t let ! are s' in t" uch h" t sur&aces- / eep c" 0 ! usti! le 0 aterial such as &urniture cushi" ns ! e##ing paper cl" thes curtains at least 1 &et &" 0 the &" nt " &the unit
- 1+ E2tre0 e cauti" n is necessar%\$hen an%heater is use# near chil#ren an# \$ hene. er the unit is le& " perating an# unatten#e#
- 3+ D" n" t " perate a &replace \$ith a #a0 age# c" r# " r plug " r i&the heater has 0 al&uncti" ne# the &replace has #r" ppe# " r #a0 age# in an%0 anner
- 4+ N" t all &replaces are suita! le &r use in ! athr" " 0 s " r laun#r%&acilities- Please c" nsult \$ith in#i. i#ual pr" #uct literature t" c" n&r0 suita! ilit%
- 5+ D" n" t run the c" r# un#er carpeting- D" n" t c" . er c" r# \$ith thr" \$ rugs runners " r the li' e- Arrange the c" r# a\$a%&" 0 tra&c area an# \$ here it \$ill n" t ! e trippe# " . er
- 6+ D" n" t 0 " #i&this &replace- Use it as #escr! e# in the 0 anual- An%" ther use n" t rec" 0 0 en#e# ! %the 0 anu&acture 0 a%cause &re sh" c' " r in(ur%&" pers" ns
- 7+ D" n" t use this heater \$ith a pr" gra0 0 er ti0 er separate re0 " te&c" ntr" l s%te0 " r an%" ther #e. ice that s\$itches the heater " n aut" 0 aticall% since a &re ris' e2ists i&the heater is c" . ere# " r p" siti" ne# inc" rrectl%
- 9+ Disc" nnect all p" \$er suppl%& e&re cleaning 0 aintenance " r rel" cati" n " &the &replace
- *: +/ eep the heater clean- D" n" t all" \$ an%" ! (ects t" enter an%. entilati" n " r e2haust " pening as this 0 a%cause electric sh" c' &re " r #a0 age t" the heater
- ** +D" n" t i0 0 erse the c" r# plug " r an%part " &the appliance in \$ater " r an%" ther li; ui#
- *, +ln " r#er t" a. " i# a ha<ar# #ue t" ina#. ertent resetting " &the ther0 al cut8' ut this appliance 0 ust n" t ! e supplie# thr" ugh an e2ternal s\$itching #e. ice

CAUTION) Pr" ce#ures an# techni; ues \$ hich i&n" t care&ull%& ll" \$e# \$ill result in #a0 age t" the e; uip0 ent-

WARNING) Pr" ce#ures an# techni; ues \$ hich i&n" t care&ull%& ll" \$e# \$ill e2p" se the user t" the ris' " &&re seri" us in(ur% illness " r #eath-

UNPACKING AND TESTING APPLIANCE

Carefully remove the appliance from the box.

Prior to installing the appliance, test to make sure the appliance operates properly by plugging the power supply cord into a conveniently located 120 volt grounded outlet.

Test all aspects of its operation "manual switches, remote and heater" to make sure all components operate correctly.


As with most electronic devices, your electric fireplace has been designed to operate at temperatures between 50°F and 90°F. During the cold winter months, allow the fireplace to reach room temperature before turning it on.

NOTE: There may be trace of odor during the first few minutes of initial use. This is normal and should never occur again.

GROUNDING APPLIANCE

This appliance is for use on 120 volts. The cord has a plug as shown in "A". An adapter as shown in "C" is available for connecting three-blade grounding type plugs to two-slot receptacles. The green grounding lug extending from the adapter must be connected to a permanent ground such as a properly grounded outlet box. The adapter should not be used if a three-slot grounded receptacle is available.

To disconnect appliance, turn controls to off, then remove plug from outlet.



CHOOSING A LOCATION FOR THE FIREPLACE

Plan where to place and frame the fireplace. Before installation consider the following,




1. The location of the fireplace must allow for wall and ceiling clearances.
2. Consider a location where the fireplace screen will not be exposed to direct sunlight from windows or doors.
3. A 15-ampere, 120 volt, 20-amp branch circuit with proper ground must be available at the location. A dedicated branch circuit should be provided to avoid circuit breakers to trip or fuses to blow.

* I' TUS +,

) escription	4ree 2tanding \$ppliance
oltage	120 \$C - 0. /
5 atts	1%005 6 ax
78 . 9\$! 9:	1; .%5
6 8! 8: . 9\$! 9:	1(5
\$ppliance 5 idth	2' <or %.- cm
\$ppliance . eight	2; 1-&<or >1.> cm
\$ppliance) epth	1> 1-2<or &&' cm
? ross 5 eight	12' .%lbs or % kgs
Plug 1ocation	1eft side
Cord 1ength	>0 >÷ @r 1; 0
+! 0	& 00

! his appliance has been tested in accordance with the 01 2tandard 2021 for fixed and location dedicated electric room appliances in the 0nited 2tates and Canada. 3 you need assistance during installation, please contact your local dealer.

NOTE: Thi! a- - #ance mu!t be e#ectrica## " ired and rounded in accordance " ith #bca# code! \$ In the ab!ence of #bca# code! % u!e the current CSA C.. \$ Canadian E#ectrica# Code in Canada or the ANSIO) PA 1, Nationa# E#ectrica# Code in the United State! \$






* I' TUS 1,

) escription	4ree 2tanding \$ppliance
oltage	120 \$C - 0. /
5 atts	1%005 6 ax
78 . 9\$! 9:	1; .%5
6 8! 8: . 9\$! 9:	1(5
\$ppliance 5 idth	2; <or >0.; cm
\$ppliance . eight	2; 1-&<or >1.- cm
\$ppliance) epth	1> 1-2<or &&' cm
? ross 5 eight	1&0.(lbs or -' .(kgs
Plug 1ocation	1eft side
Cord 1ength	1; 0 cm
+! 0	& 00

! his appliance has been tested in accordance with the 01 2tandard 2021 for fixed and location dedicated electric room appliances in the 0nited 2tates and Canada. 3 you need assistance during installation, please contact your local dealer.

NOTE: Thi! a- - #ance mu!t be e#ectrica##y " fixed and rounded in accordance " ith #bca# code! \$ In the ab!ence of #bca# code! % u!e the current CSA C.. \$ Canadian E#ectrica# Code in Canada or the ANSIO) PA 1, Nationa# E#ectrica# Code in the United State! \$



MEDIA OPTIONS

Your fireplace shipped with DESIGN-MEDIA-BIRCH-1 !CE"



DESIGN-MEDIA-BIRCH-10PCE



STES /H No% "ou !an de!orate "our firepla!e#

MEDIA INSTALLATION

STES 'H 8nplug the unit and ma-e sure !ontrols are s%it!hed off#

STES (H Ta-e off the top !over#



ST\$P (%&fter the media has been installed' reinstall the front door and top cover.

STES +H \$ull the front door up and ta-e it off#




OPERATION

The fireplace can be operated by the switch located on the left front of the fireplace unit or by remote control (included).



MANUAL OPERATION



- ' # The main power ON/OFF switch in position O* the fireplace is OFF#
- (# : When main power ON/OFF switch is at position I* the fireplace is ready to use#
- + # Press the  button repeatedly to set the heater to desired heat setting# The heater indicator LED will glow. High shows the current heater settings#
 - a# RED -55: HEAT ON/STANDBY
 - b# ;< 0-5: HEAT ON/STANDBY
 - !# \$@R\$<E A@TO MODE

A@TO MODE

Under this mode the heater will automatically turn ON at high heat setting -55: heat output when the room temperature drops below (C 70C) # : When the room temperature is between (C 60 - 70C) the heater output will switch to low heat setting 0-5: # : When the room temperature goes above (C 70C) the heater will be turned off and the LED will continue# The LED indicator will be \$@R\$<E in colour under this mode#


- , # Flame effect# Press the button marked  to adjust the flame brightness# The flame brightness will change through Dim/Medium/High/Off#
- # Mood light effect# Press the button marked  to change the mood light colour#

NOTE: If operated at the low heat setting* the fireplace will not provide as much heat as in the High setting* however* the low setting will not require as much electrical power# To avoid overloading the circuit* do not plug the fireplace into a circuit that already has other appliances working connected# When the fireplace is not in use* switch off and unplug#

SAFETY CUT-OFF

This appliance is fitted with a safety cut-off which will operate if the fireplace overheats due to blocked air vents# For safety reasons* the fireplace will NOT automatically reset# To reset the appliance* disconnect the appliance from the main supply for at least 5 minutes# Reconnect the supply to the main and switch on the appliance#

REMOTE CONTROL OPERATION



For remote to function make sure the heater is plugged in and main power switch located on the bottom left hand side is at position I#

: When operating the remote make sure "you point the remote to the center of the fireplace and make sure each time "you press the button the buzzer inside the unit will beep once# It takes some time for the receiver to respond to the transmitter# Do not PRESS the buttons more than once within 10 seconds for correct operation#

Power on button# The power button at top left corner of the remote is the main ON/OFF power button# This will turn off all the functions and the fireplace will be in standby mode#

DISPLAY ON/OFF button# Switches the fireplace flame and tray light on and off. It will store the last setting.

DISPLAY BLUE button, Adjusts the blue color and brightness of flame and tray.

DISPLAY YELLOW button, Adjusts the yellow color and brightness of flame and tray.

DISPLAY ORANGE button, Adjusts the orange color and brightness of flame and tray.

MOOD LIGHT ON/OFF button# Switches the mood light On and Off##

ADJUST button# Switches the color of the mood light#

FLASH button# Switches the mood light into flash mode# This cycles through all mood light colors#

(EATER ON/OFF) button, Turns the heater on and off. It will store the last setting.

(HIGH) button, Press the high button to switch the heater to high heat setting 100% .

LOW button, Press the low button to switch the heater to low heat setting 50% .

TEMP button, Press the TEMP button to switch the heater to 8 mode. Under this mode the heater will operate as explained in the manual operation.


REPLACEMENT PARTS

This list contains replacement parts


NO	PART NUMBER		DESCRIPTION	QTY
	E 50	E 70		
2	10701381	10701382	FRONT GLASS	1
3	10702263	10702265	BOTTOM GLASS	1
4	10702262	10702264	BACK GLASS	1
7	3224505	3225505	FLICKER ASSEMBLY	1
8	601136B		LED STRIP	
	601141B		LED STRIP	
	6010 7B		CIRCUIT BOARD	1
11	602067D		BLOWER AND HEATER ASSEMBLY#FRT45\$187%	1
12	10105063		REMOTE CONTROL	1
13	601036		CONTROL PANEL	1
14	10101225		FLAME MOTOR	1
15	10104002		SMOKE DETECTOR	1

NOTE: () * + , * - . / + , * - . 01 , ' / 2.1 (' () *) - 1 , 3 4 5 6 * + 7 1 - ' ,) * 4 7) 5 , 1 * * 7 ' ' 8 0 .) 3 ' 3 % ' 5 :

E6PLODED * IE4



Wiring Diagram



TROUBLE SHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
Dim or no flame	Flame LED s are burnt out	Inspect the LED s and replace them if necessary.
	Back black cloth is falling off and rolled up in the flicker	Change a flicker and back black cloth.
Ember bed is not glowing or dimming	Ember LED s are burnt out	Inspect the ember bed LED s and replace them if necessary.
Appliance turns off and will not turn on	Appliance has overheated and safety device has caused the thermal switch to disconnect	Turn off the main switch, allow appliance to cool for 10 minutes, then turn it on.
	House circuit breaker has tripped	Reset house circuit breaker.
	Appliance s fuse has blown	Replace the fuse.
Appliance will not come on when switch is flipped to ON	Appliance is not plugged into an electrical outlet	Check plug and plug in.
	Appliance has overheated and safety device has caused the thermal switch to disconnect	Turn off the main switch, allow appliance to cool for 10 minutes, then turn it on.
	Circuit board is burnt out	Inspect the circuit board and replace it if necessary.
No warm air coming out of appliance	Heater is burnt out	Inspect the burner and heater assembly and replace it if necessary.
Flame sputters	Flame motor is defective.	Call a qualified service technician and replace flame motor.
Remote Control does not work.	Low batteries. Unit switch in "O! position.	Replace AAA batteries in remote control. Turn the switch in "I! position.
Flame is fixed.	Wiring may be loose or the flame motor may be defective.	

SERVICE HISTORY:

This heater must be serviced annually depending on usage.

Date	Dealer Name	Service Name	technician	Service Performed	Special Concerns

NOTES

WARRANTY FOR PRODUCTS MANUFACTURED AFTER JANUARY 1st, 2016

Amantii Imports Corp. ("Amantii") warrants that your newly purchased Amantii electric fireplace is free from manufacturing and material defects for a period of two (2) years from the date of the first purchase, subject to the conditions and limitations contained below.

Warranty Application & Exclusions

This limited warranty applies to your newly purchased Amantii electric fireplace; the limited warranty's application is limited to purchases made in any province of Canada or in any of the 52 States of the United States of America, including the District of Columbia. Only the original purchaser of the product is eligible for coverage under this limited warranty; the warranty is not transferable.

Products excluded from this limited warranty

Light bulbs are not covered by this limited warranty and are the sole responsibility of the owner/purchaser. Amantii does not cover service or labor charges.

Warranty Coverage and Term

Products covered by this limited warranty have been tested and inspected prior to shipment and, subject to the provisions of this warranty, Amantii warrants such products to be free from defects in material and workmanship for a period of two (2) years from the date of the first purchase of such products.

The limited two (2) year warranty period for products also applies to any implied warranties that may exist under applicable law. Some jurisdictions do not allow limitations on how long an implied warranty lasts, so the above limitation may not apply to the purchaser.

All other warranties—expressed or implied—with respect to the product, its components and accessories or any obligation/liabilities on the part of Amantii are hereby expressly excluded.

Limitations to Coverage Under Limited Warranty

This limited warranty does not apply to products that have been repaired, except by Amantii or its authorized service representatives, or otherwise altered. This limited warranty further does not apply to defects resulting from misuse, abuse, accident, neglect, incorrect installation, improper maintenance or handling, or operation with an incorrect power source. Products made by other manufacturers, sold with the product or thereafter, are not covered by this limited warranty. The use of unauthorized components will render this warranty null and void.

Panorama Outdoor Units

All Panorama units that are installed outdoors or in moisture intense conditions must use the stainless steel cover. Proof of purchase of the cover is required for any warranty claims.

Defects

Defects must be brought to the attention of the selling dealer. Please have your proof of purchase, catalogue/model and serial numbers available when contacting dealer; any and all service under the limited warranty requires a proof of purchase of the product. Should a product or part covered by this limited warranty be proven to be defective, in material or workmanship, and during the two (2) year limited warranty period, Amantii will replace such defective product or part without charge. If Amantii is unable to replace such product, or if replacement is not commercially practicable or cannot be timely done, in its sole discretion Amantii may, in lieu of replacement, choose to refund the purchase price for such product or part. Amantii does not cover labor or service charges to replace said parts.

Limitations

In no event will Amantii, including without limitation any of its directors, officers, shareholders, employees, consultants, agents, heirs, executors, administrators and assigns, be liable to the purchaser or any third party, whether in contract, in tort, or on any other basis for any indirect, special, punitive, exemplary, consequential, or incidental loss, cost or damage arising out of or in connection with the sale, maintenance, use or inability to use the product, even if Amantii, including without limitation any of its directors, officers, shareholders, employees, consultants, agents, heirs, executors, administrators and assigns, have been advised of the possibility of such losses, costs or damages, or if such losses, costs or damages are foreseeable. In no event will Amantii, including without limitation any of its directors, officers, shareholders, employees, consultants, agents, heirs, executors, administrators and assigns, be liable for any direct losses, costs or damages that exceed the purchase price of the product.

Some jurisdictions do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion may not apply to the purchaser.

Application of Provincial and State Law

This limited warranty gives you specific legal rights, and you may also have other rights which vary from jurisdiction to jurisdiction. The provisions of the United Nations Convention on Contracts for the Sale of Goods shall not apply to this limited warranty or the sale of products covered by this limited warranty.

General

Amantii reserves the right to make changes at any time without notice, in design, material, specifications, prices and the right to discontinue styles and products.