## Troubleshooting

PROBLEM	SOLUTION
Steamer has NO Power	Check electrical panel for tripped breaker:  The steam cleaner should be the only appliance plugged into the outlet  Use only a 12 gauge / 15AMP rated or higher extension cord.
Power but NO Steam	Check the STEAM DIAL on top of the Eagle.  1) Turn steam control dial to the LEFT.  2) Disconnect the hose and reconnect.  You will hear a "click" when connected.  1) Check grey safety lock on hose handle.  2) Is the steam number on the display reading "2"?
	3) If yes, push and hold power button until it shows a 1 or 3
Squeeze Trigger and NO steam	Check hose connection:  Disconnect and reconnect  You should hear a "click" when connecting hose to the steamer  Check the grey safety lock on the side of the handle
Steam pressure last 10 minutes	<ul> <li>You are cleaning using HIGH steam.</li> <li>Reduce steam pressure to MEDIUM.</li> </ul>
Low Water Indicator is flashing	<ul> <li>Add water to the steamer.</li> <li>Push power button to reset alarm.</li> </ul>
Shuts off after 30 minutes	<ul> <li>The Eagle will automatically shut off after 30 minutes of continuous use.</li> <li>Push power button to reset.</li> </ul>
Steamer takes longer than 15 minutes to heat	Have you descaled the boiler?  Your steamer needs to be descaled every 6 months or when you notice a reduction in steam pressure
If you are still having	ng problems, contact our service team at (817) 888-8313

## Troubleshooting

PROBLEM	SOLUTION
ERROR CODES	E01 – Refill Water Tank E03 – Refilling the boiler failed. E05 – Descale the boiler

If you are still having problems, contact our service team at (817) 888-8313

