

Santa Fe Rx Laminate Top Kit

Please read these instructions before modifying the Santa Fe Rx to use the Laminated Top

1. Tools required. A medium size phillips screwdriver.
2. Remove the posts using the phillips screwdriver.
3. Remove the release paper from the $\frac{1}{2}$ " diameter by $\frac{1}{4}$ " high bumper pad and attach it over the locating hole as indicated
4. Attach the $\frac{3}{4}$ " diameter by 1" high rubber bumpers to the outer holes as indicated using the phillips screwdriver and the screws provided.
5. Place the laminated top so the holes in the bottom of the laminated top rests over the $\frac{3}{4}$ " diameter by 1" high rubber bumpers.

