

Desert Spring  Products™

## Desert Spring Overflow Kit

Designed For Installation With  
DS3200/DS2001/DS2000 Model Humidifier Systems

### INSTALLATION INSTRUCTIONS

#### COMPONENTS INCLUDED

1 Hose Barb Connector                      8 ft. – 3/8" Drain Hose  
1 1/4" Pipe Nut                                1 O-Ring

*If you discover missing or damaged components, please call us toll free at 1-888-486-4324 or email us at [info@desertspringproducts.com](mailto:info@desertspringproducts.com).*

#### REQUIRED TOOLS

9/16 wrench (or adjustable wrench)

**CAUTION:** This device requires a floor drain. This product is designed only for the intended use as outlined in the manufacturer's instructions.

**WARNING:** SHUT OFF THE WATER SUPPLY TO YOUR HUMIDIFIER AND DRAIN THE BASIN BEFORE INSTALLING THE DESERT SPRING OVERFLOW KIT. ALL PLUMBING CONNECTIONS MUST CONFORM TO LOCAL CODES.

#### Step 1

Shut off the water supply to your humidifier and drain the basin

#### Step 2

Using a screwdriver, knock out the plastic knock-out located below the float opening on the right side of the humidifier basin. Run the edge of the screw driver around the opening, ensuring all excess plastic is removed.

#### Step 3

Attach the O-ring to the barb connector and using a 9/16" wrench thread the barb connector through the opening in the basin until O-ring meets the outside plastic side of the basin. Attach lock nut to barb fitting on the inside of the basin.

#### Step 4

Attach hose to the barb end of the connector and run hose to floor drain. Trim hose as required.