

March, 2017

DS-AF15 AutoFlush - Installation and Operation Guide – Addendum

Designed For Installation With All Desert Spring Rotary Disc Humidifier Models.



Frequency:

- Used to set the interval time between flushes from 1 hour up to 72 hours (3 days)
- We recommend starting with 48 hours interval time, adjust if necessary

Run-time:

- Used to set the length of the flush from 1 minute up to every 120 minutes (2 hours)
- We recommend starting with 3 minute flush time, adjust if necessary

Battery:

- Only use high-quality, alkaline AAA batteries (2), discard test batteries and do NOT use rechargeable batteries
- Battery light flashes when there are batteries in the unit
 - Slow flashes (every 3 – 4 seconds): batteries are good
 - Rapid flashes (every second): insufficient power left in batteries