



# DryLINK Asset Manager

## OVERVIEW OF GATEWAYS AND TAGS

Thank you for choosing **DRYLINK ASSET MANAGER GATEWAYS**. In order for Asset Manager to perform correctly, every warehouse and vehicle that stores or transports equipment should have a gateway.

Every dehumidifier on the market including DryMAX XL and DryMAX BLE (Smart Equipment) will need a **DryTAG**. If your dehumidifier is not Smart and you want to take advantage of DryLINK for jobs (Including automated temperature and RH), please install a **DryTAG RH**.

Any equipment to be tracked (including Air Movers, HEPA units, Hydroxyls, etc.) will need a DryTAG or a DryTAG RH.

DryTAG RH



Scan QR code for more information on **DryLINK ASSET MANAGER GATEWAYS**



The DryLINK Asset Manager Gateway has three 3-year batteries onboard. It transmits even when vehicles are off. It can also be used in storage warehouses and temporary staged locations.

### GATEWAY KIT (1-1, 1-2, 1-3)

Please inspect and unpack your kit and make sure all components are accounted for.

In your Gateway Kit you will find:

- |   |   |
|---|---|
| 1 ea Multi Antenna Gateway                | 1 ea 110 volt AC Adapter 12V Power Port |
| 1 ea BLE Antenna                          | 1 ea Lever Nut                          |
| 1 ea LTE/GPS Antenna (Puck)               | 3 ea RF Coaxial Extension Cable         |
| 1 ea Push Button Assembly                 | 1 ea SAE DC Jack Cable                  |
| 1 ea Power Extension Cable (6 m)          | 1 ea SAE Polarity Adapter               |
| 1 ea Power Cable - Cigarette Lighter(2 m) |   |

