



MODEL PART DIAGRAM



WHERE TO USE



Allow 12 ~ 18 in. of space between TVs, radios, and other electronics. Electromagnetic interference from certain electronics may cause product malfunction.


Place indoors away from direct sunlight
Direct exposure may cause product malfunction or failure.

Only place on hard, flat surfaces
Flimsy or slanted surfaces may result in abnormal noise and vibrations.

Allow at least 12 ~ 18 in. from walls for maximum air flow


1

CONTROL PANEL



2

4-STAGE AIR PURIFICATION



- 01. Pre-Filter**
Designed to catch larger airborne particles found indoors.
- 02. Activated Carbon Filter**
Reduces VOCs and household odors from cooking, pets, and smoke.
- 03. True HEPA Filter**
Captures 99.99% of airborne allergens including pollen, dust, smoke, pet dander, and other ultrafine particles as small as 0.003 microns.
*Based on independent laboratory tests conducted on inanimate particles as small as 0.003 microns.
- 04. PlasmaWave®**
Winix PlasmaWave® Technology may help to reduce airborne contaminants.*
*Tested by an independent third-party laboratory. Visit www.winixamerica.com for more details.

MAINTENANCE


When to Replace Filters

Filter	Indicator Light	When to Service	When to Replace
Pre-Filter	none	Clean once every 14 days	Permanent
Activated Carbon Filter	none	Can NOT be WASHED	Replace every 3 months
True HEPA Filter			Lasts Approx. 12 months

- When the Check Filter Indicator LED is flickering, it is time to replace the Filter.
- Intervals between filter replacement may vary depending on environment.

4

INITIAL OPERATION



5


REPLACING FILTERS



Resetting Filter Life:
After replacing your True HEPA Filter, place the Pre-Filter back in and close the Front Panel. While the unit is on, hold the Filter Reset Button for at least 5 seconds until you hear the beep. After the beep, the Filter Replacement Indicator will disappear. Your Winix True HEPA is now reset.

CLEANING CARE

Cleaning the Filters:




Use a vacuum cleaner or soft brush to clean the Pre-Filter

- If it is excessively soiled, rinse in room temperature water.
- Do not use detergent or soap.
- Allow the filter to dry for 24 hours or more before using.
- Intervals between filter cleaning may vary depending on the air quality.
- Do not use hot water over 104°F or volatile fluids such as paint thinner.

NOTICE

Do not use benzene, alcohol, or other volatile fluids, which may cause damage or discoloration.

Cleaning the Exterior & Interior:



Wipe with a soft damp cloth using room temperature water.

- Afterwards, wipe it down with a clean, dry cloth.

Open the front panel and clean the interior with a vacuum cleaner.

- For optimal performance, clean every 1 - 2 months.

NOTICE

- When cleaning the unit, always unplug the power cord first and then wait until the unit has cooled down.
- Never disassemble, repair, or modify this unit yourself.
- Do not use flammable sprays or liquid detergents.
- Do not allow children to clean or maintain the unit.
- Before cleaning or maintaining, ensure unit is unplugged.

6

SAFETY AND CAUTIONS

Before operating this equipment, carefully read and follow these safety cautions.

Ensure filters are inserted before running unit.

Running the unit without filters can shorten the lifespan of the unit and cause electric shock or injury.

Be sure foreign objects are NOT inserted into the vents on the unit.

Objects can include pins, rods, and coins.

Do not touch any part of the interior of the unit with wet hands.

The high voltage may cause electric shock.

Ensure unit intake and outlet vents do not become blocked.

Blockage may lead to increased internal temperatures, causing product failure and deformation.

Do not use the unit as a step stool or place heavy objects on the unit.

Personal injury may occur or product failure and deformation.

WARNING

Follow these instructions to reduce the risk of serious injury or death and to reduce risk of damaging the unit.

- If the power cord is damaged, it must be replaced by a special cord. Reassembly is available from the manufacturer or its service agent.
- This appliance is not intended for use by a person (including children) with reduced physical sensory or mental capabilities, or lack of experience and knowledge of the unit, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Children should be supervised to ensure that they do not play with the appliance.
- This unit is not intended to be used to preserve documents or art conservation.

7

FREQUENTLY ASKED QUESTIONS

The unit does not turn on at all.

- Is the plug securely attached to the outlet?
 - Make sure the outlet has power going to it and ensure the plug is secured.

- Is there a power outage?
 - Check to see if other lights and electrical equipment are working and try again.

The unit doesn't work in Auto Mode.

- Has Auto Mode been selected?
 - Press the Fan Speed button until Auto Mode is selected.
- Is the sensor blocked or clogged?
 - Wipe Smart Sensor with wet cloth, then dry.

It vibrates and makes a lot of noise.

- Is it running on a slanted or uneven surface?
 - Move the unit to a hard, flat, even area.

PRODUCT WARRANTY

The terms of the warranty are as follows:

1. This product is manufactured under stringent quality control and inspections.
2. The warranty will be voided if product failure is a result of negligence or misuse by the consumer.
3. A proof of purchase must be presented upon claiming a Product Warranty.
4. Store the proof of purchase in a safe place or register your product on winixamerica.com to upload your proof of purchase.
5. This warranty is valid only in the USA and Canada.

• For more information visit
<https://winixamerica.com/terms-and-conditions/>

- ⚠ Do not pull on the power cord when unplugging the unit.
- ⚠ Do not tie or knot the power cord when unit is in operation.
- ⚠ If the unit becomes submerged in water, unplug it and contact customer service.
- ⚠ Do not unplug or move the unit while in operation.
- ⚠ Do not plug additional appliances into the same outlet or power supply.
- ⚠ Do not touch the plug with wet hands.
- ⚠ Unplug the unit when not in operation for extended periods of time.
- ⚠ Do not place around heating elements.
- ⚠ Do not use around mist or fumes from industrial oil or around large quantities of metallic dust.
- ⚠ The cord can become damaged by forcefully bending, pulling, twisting, bundling, pinching or placing heavy objects on it.
- ⚠ Do not install in any sort of motor or transport vehicle (trucks, boats, ships, etc.).
- ⚠ Do not place in an area with excessive amounts of noxious gases.
- ⚠ Do not place near any flammable materials (aerosols, fuel, gases, etc.).
- ⚠ Do not have the unit facing into wind or drafts.
- ⚠ Do not place below any electrical outlet.
- ⚠ Do not place in excessively humid areas where the unit may become wet.
- ⚠ Do not place unit closer than 12 inches from the wall during operation. It may cause condensation on the wall and the surrounding area.

SAFETY INSTRUCTIONS

Thank you for purchasing a Winix air purifier. This product is for household use only.

IMPORTANT CAUTIONS FOR USING YOUR AIR PURIFIER:

WARNING: Follow the instructions in this manual to reduce the risk of electric shock, short circuit, and/or fire.

- Do not repair or modify the unit. All repairs should be completed by a qualified technician.
- The plug for this unit is polarized with one blade wider than the other. Do not force the plug into an electrical outlet. Do not alter the plug in any way. If the plug does not fit into the outlet, reverse the plug. If it still does not fit, contact a qualified technician to install a proper outlet.
- Do not use if the power cord or plug is damaged or the connection to the wall outlet is loose.
- Use AC 120V only.
- Do not damage, break, forcefully bend, pull, twist, bundle, coat, pinch, or place heavy objects on the power cord.
- Periodically remove dust from the power plug. This will reduce the risk of shock due to humidity build up.
- Remove the power plug from the outlet before cleaning the unit. When removing the power plug, grasp by holding the plug itself, never hold by the cord.
- If the power plug is damaged, it must be replaced by the manufacturer or a qualified technician.
- Remove the power plug from the outlet when not in use.
- Do not handle the power plug with wet hands.
- Do not operate the unit when using indoor smoke-generating insecticides.
- Do not clean unit with benzene or paint thinner. Do not spray insecticides on the unit.
- Do not use the unit where it is humid or where the unit may become wet, such as the bathroom.
- Do not insert fingers or foreign objects into air intake or outlet.
- Do not use the unit near flammable gases. Do not use near cigarettes, incense, or other spark-creating items.
- Unit will not remove carbon monoxide emitted from heating appliances or other sources.

IMPORTANT PRECAUTIONS FOR USING YOUR AIR PURIFIER:

- Do not block the intake or outlet vents.
- Do not use near hot objects, such as a stove.
- Do not use where the unit may come into contact with steam.
- Do not use the unit on its side.
- Keep away from products that generate oily residue, such as a deep fryer.
- Do not use detergent to clean the unit.
- Do not operate without a filter.
- Do not wash and reuse the True HEPA Filter.
- Hold the handle on the back of the unit to transport.
- Do not hold by the front panel.
- Do not stick any small objects into the air outlet vents or fan.

8

UNIT SPECIFICATIONS

Model Name	9800
Power Voltage	AC 120 V / 60 Hz
Power Rate	95 W
Verified Room Size	500 sq.ft.
Dimensions	16.5 in(W) × 11.8 in(D) × 23.2 in(H)
Weight	18.7 lbs
Replacement Filter	Filter A / SKU: 115115

The exterior, design, and product specifications may be changed without prior notice to improve product performance.

Warning: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device contains license-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's license-exempt RSS(s). Operation is subject to the following two conditions:

- This device may not cause interference.
- This device must accept any interference, including interference that may cause undesired operation of the device.


*In French: Cet appareil contient des émetteurs/récepteurs exempts de licence et conformes aux normes Innovation, Science et Économie. RSS(s) sans licence de Développement Canada. Le fonctionnement est soumis aux deux conditions suivantes:

- cet appareil ne doit pas causer d'interférences nuisibles, et
- cet appareil doit accepter toute interférence reçue, y compris les interférences pouvant provoquer un fonctionnement non souhaité.*

WINIX

User Manual

AIR PURIFIER



Model 9800

Use & Care Guide

- The product warranty is printed on the back of this guide.
- This product is manufactured for use only in USA / CA.
- This product is suitable for 120 V only.



The energy efficiency of this ENERGY STAR certified model is measured based on a ratio between the model's CADR for smoke and the electrical energy it consumes, or CADR/Watt.



WINIX

Contact Winix for product related inquiries and customer service

- Dedicated Call Center: ☎ (877) 699-4649
- Website: www.winixamerica.com

To expedite service, please specify the model name and number, the nature of the problem, your contact information, and your address.

2610-0286-00 Rev.02

9

10